## 7 test voltage ranges Insulation Resistance Tester.

## **HG561H**







CE

Though it is pocket size, when measuring M $\Omega$ , the rated current is more than 1 mA.

- $\blacksquare$  Automatically-held readings after measuring M $\Omega$  The LED level meter shows the reading
- ■The instrument makes only necessary voltages enabled between 15V, 25V, 50V, 100V, 125V, 250V, and 500V
- ■Easy-to-read LCD with the fixed decimal point.
- Provides the probe that enables you to measure through a hole of a circuit breaker cover.
- The lighting lamp illuminates a place to be measured, and the LCD has a backlight.



Safety: JIS C 1302 IEC61010 CAT.III 300V / CAT.II 600V IEC61557

HG561H	Measuring range	Best accuracy	Resolution
ΜΩ	15V / 25V / 50V 9.99MΩ / 21.0MΩ 100V / 125V / 250V / 500V 9.99MΩ / 99.9MΩ / 110M	±(2%+5)	0.1ΜΩ
Test voltage	15V / 25V / 50V / 100V / 125V / 250V / 500V		
ACV / DCV	600V(AC/DC automatically selectable)	±(1.6%+7)	0.1V
Ω	999.9Ω / 99.99kΩ / 999.9kΩ	±(1.5%+7)	0.1Ω
Insulation (Level meter)	15V / 25V / 50V 5 step(LED illumination or blinking) 100V / 125V / 250V / 500V 7 step(LED illumination or blinking)		
Continuity	Buzzer sounds at less than $30\Omega$		
Battery	LR03 x 4		
Size / Weight	H139 x W91 x D29mm / 230g		
Standard accessories included	Test Lead(TL-561), Aligator Clip(CL-561), Carrying Case(C-DG3a), Instruction Manual		